

Mitsubishi Triton MQ MR 2.4L 2015-on 4N15 DI DOHC 16V

OS-14-FM



**\*\* Don't buy this kit if you want to include a second battery !! \*\***

Use this guide to assist in the installation of the Western Filters, very own Pre-Filter Kit with our unique Bracket which can mount either a Fuel Manager or a Racor.

**Notes: \*\* Ensure ENGINE is OFF and is COOL to touch ! \*\***

1. Identify installation area (empty bay behind battery - img.1.)
2. Configure Head Assembly with proper fittings using supplied sealant. Allow 5mins to dry (img.2).
3. Mount bracket to engine bay base (img.3)
4. Mount unit to bracket (img.4)
5. Disconnect the Factory Feed Line (FFL) from the tank (img.5)
6. Re-connect FFL to the Pre Filter's Inlet (img.6)
7. Using the supplied Kit Hose, connect one end to Factory Fuel Inlet and the other to the Pre Filter's Outlet (img.7)
8. Turn ignition ON / OFF without starting the car - several times, to prime the fuel filter and then start the engine.

