



INSTRUCTIONS

Roller Cover Cross Bar

www.trailbait.com.au

1.

Fit 2 x M6 bolts to the 'Z' brackets. Attach channel nut by threading one turn.



2.

Slide the Z bracket into the tracks from the cabin end of the roller shutter.

Position the Z brackets opposite each other. Hand tighten bolts only, as the bracket still needs to slide into position.



3.

Slide two nuts in either end of the bar.



4.

Place the cross bar on top of the Z brackets, lining the nuts up with the holes. Before tightening the brackets too much, ensure the cross bar is centred on the vehicle.

Once happy with the position, tighten all bolts and install the end caps.

