

VEHICLE Isuzu D-Max / Mazda BT50 2020+

PRODUCT 10mm Diffdrop Kit

PRODUCT CODE DDDMAX20-10

NOTE Suggested fitment by a 4WD specialized mechanic

HARDWARE SUPPLIED:

- 2x M14 (P1.5) x 80L Bolts Hexagon Bolts - Half Thread
- 2x Spring Washers
- 2x Flat washers

COMPONENT LIST:

- 2x Spacers

TOOLS REQUIRED:

- General Hand Tools

1. Raise vehicle and support securely.
2. Remove wheels and bash plates.
3. Support the front differential appropriately.
4. Undo the two bolts in **Figure 1**.
5. Lower the front differential and insert spacers above the bush as in **Figure 2**.
6. Fit supplied bolts and washers to the vehicle and tighten to the correct torque settings.
See **Figure 3**.
Tip: Unbolting the rear crossmember and lowering the diff evenly can help align the front bolts.
7. Check that the breather hose still reaches the breather outlet on top of the differential housing.
Tip: If the breather hose no longer reaches the differential housing, a Blackhawk4x4 Diff Breather Kit can be used to connect the differential breather to the body hardline.
8. Refit the bash plates and wheel and lower vehicle to the ground.
9. Torque wheel nuts to the factory specs.

