



TOW-PRO BRACKET BEHIND DASH

TLR711205



SUITED TO:

TOYOTA LANDCRUISER 70 SERIES RANGE



FITTING INSTRUCTIONS

1. Install the Tow-Pro Module to the TLR Products Bracket using the M4 hardware supplied in the fitting kit, Orientate as per photo on previous page.
2. Remove the 2x M6 accelerator pedal mounting nuts shown below and move pedal assembly out the way.
3. Position the TLR Products Bracket and Tow-Pro assembly over the accelerator mounting studs and reinstall the pedal assembly and previously removed mounting nuts to secure into position.
4. Connect the electrical plugs to the Tow-Pro module and finalise all wiring to complete installation.



[instagram.com/tlrproducts](https://www.instagram.com/tlrproducts)
[facebook.com/tlrproducts](https://www.facebook.com/tlrproducts)



hello@tlrproducts.com.au
www.tlrproducts.com.au



TLR Products
65 Northville Drive
Barnsley NSW 2278