



SOLAR PANEL BRACKETS

TLR760002



SUITED TO:

ARB BASE RACK/MESH PLATFORMS



PRE-INSTALLATION



Read through this installation guide before proceeding.



Fitting time is approx. 30 minutes.



Allen key set, drill/ drill bit 6.5 mm, Phillips head screwdriver, spanner

FITTING KIT	
QUANTITY	PART
4	TLR760002-1
4	TLR760002-2
8	M6 x 50 mm SS Button Head Socket
8	M6 SS Nyloc Nut
16	M6 x 12 mm SS Flat Washer
8	M6 x 12 mm Pan Phillips Head
8	M6 x 20 mm Flat Washer
8	M6 Nyloc Nut



NOTE:
The TLR Products Solar Panel Mounting Bracket set is designed to be used with the ARB BASE RACK or other brand racks /baskets where a clamping style bracket is required



FITTING INSTRUCTIONS

1. Place Solar Panel in desired location on roof rack, mark bracket locations on panel.
2. Remove panel, place brackets on panel, mark holes to be drilled then drill 6.5 mm holes using a drill stopper to prevent damage to solar panel.
3. Mount brackets to panel using M6 x 12 mm bolts, M6 flat washer and M6 nyloc nuts supplied.
4. Place solar panel on roof rack, fix brackets using M6 x 50 mm bolts, M6 flat washer and M6 nyloc nuts.



[instagram.com/tlrproducts](https://www.instagram.com/tlrproducts)
[facebook.com/tlrproducts](https://www.facebook.com/tlrproducts)



hello@tlrproducts.com.au
www.tlrproducts.com.au



TLR Products
65 Northville Drive
Barnsley NSW 2278